

# NC SHINE

---



## APPLICATION INSTRUCTIONS



USE MASK



USE GLOVES



KEEP AWAY FROM  
OPEN FIRE



MAKE SURE FOR  
GOOD VENTILATION

INSTRUCTIONS AND USE SHOULD BE FOLLOWED  
STRICTLY.

---



## CONDITION OF SUBSTRATE

- The substrate to be coated must be clean, grease-free and **absolutely dry**.
- On areas which are difficult to reach, must be dried additionally with absorbent cloths or blown dry with compressed air.
- On contact with a damp substrate surface, the product reacts prematurely and cannot form a permanent seal.
- The substrate temperature must be between 41° F. / 86° F, the relative humidity at 30-80 %.
- Suitable for non-absorbent surfaces.
- Depending on how absorbent the surface is, test in small areas before application. ( Do not apply Fiberglass / PVC surfaces before 2005 )



DANIEL@DCIFILMS.COM  
305-640-0295

WWW.DCIFILMS.COM

7866 NW 62ND STREET  
MIAMI, FL 33166, USA

# NC SHINE

---



## CLEANING

### STEP 1

- 1- Wash the surfaces with High pressure machine (wide sprinkler) with clear water
  - 2- Apply foam cleaner or snow foam.
  - 3- Wash the surfaces with High pressure machine (wide sprinkler) with clear water, rinsing procedure.
  - 4- Cleaning procedure. Neutral cleaner and water (manually).
  - 5- High pressure machine with clear water to remove previous cleaners residues.
  - 6- Chemical decontamination (recommended).
  - 7- Polish the paint to remove minor scratches.
  - 8- Remove residues with alcohol.
  - 9- Make sure the surface is grease free, previous cleaners dust, etc. (use alcohol, basic or acid cleaners).
- 



## APPLICATION

### STEP 2

Complete removing of minor scratches is highly recommended.

After Bodywork cleaning, **NANO CAR SHINE** must be apply by rubbing on horizontal movements. For spray application, make sure all the surface has been covered.

The material has to be rubbed on the surface in a thin film. **Use per car middle range : 1.30 - 2.00 oz.**

---



DANIEL@DCIFILMS.COM  
305-640-0295

WWW.DCIFILMS.COM

7866 NW 62ND STREET  
MIAMI, FL 33166, USA

# NC SHINE

---

1- By Hand, use a soft pad or lint free cotton cloth which has been impregnated with the product. Or by machine using a soft polishing pad.

2- Work on controlled areas horizontal movements.

3- Excessive product can be removed with a clean dry microfiber.

4- **The material has to be completely rubbed on the surface till no drops will appear.**

5- The formed film is completely invisible and will no lead to any optical impairment on the surface.

## Drying:

The product should not come into contact with water before or during the application.

The coated surface has to be dried **in 2 hours** at room temperature.

---



## FINISHING

### STEP 3

- Residues has to be gently removed within 2 hours
- 



## CURING

### STEP 4

- Complete curing **24 hour**.
  - The effect of the product will last at least **18 months**.
- 

COMPLETE TECHNICAL DATA & SAFETY MEASURES ON TDS, ASK YOUR DISTRIBUTOR IF NECESSARY.

---



DANIEL@DCIFILMS.COM  
305-640-0295  
WWW.DCIFILMS.COM

7866 NW 62ND STREET  
MIAMI, FL 33166, USA