

# NANO STONE

---



## APPLICATION INSTRUCTIONS



USE MASK



USE GLOVES



KEEP AWAY FROM  
OPEN FIRE



MAKE SURE FOR  
GOOD VENTILATION

INSTRUCTIONS AND USE SHOULD BE FOLLOWED  
STRICTLY

---



## CONDITION OF SUBSTRATE

- The substrate to be coated must be completely clean, grease free and **absolutely dry**.
  - On areas which are difficult to reach, such as cavities or drainage channels etc. must be dried additionally with absorbent cloths or blown dry with compressed air.
  - On contact with a damp substrate surface, **NANO STONE** reacts prematurely and cannot form a permanent seal.
  - The substrate temperature must be between 41° F / 86° F, the relative humidity at 30-80%.
  - **Coverage by liter 215- 538 ft2.**
  - Avoid direct **sunlight**.
  - Apply the coating in dry conditions and never in rain.
  - The coating is applied with an applicator , brush or roller.
  - The product is also suitable for spray application.
- 



DANIEL@DCIFILMS.COM  
305-640-0295  
WWW.DCIFILMS.COM

7866 NW 62ND STREET  
MIAMI, FL 33166, USA

# NT STONE

---



## APPLICATION

### STEP 1

Protect non stone areas such metal, plastic, textil.

### STEP 2

Remove and repair scratches and non fixed cemented portions. Mask non mineral areas such metal, plastic, textil.

### STEP 3

Apply the solution with a spray gun, brush or roller. All areas must be covered. (Brush recommended).

### STEP 4

Re-apply one second layer within minutes of the first layer depending of the level protection required.

After this, the repellent effect makes it impossible to apply another coating.

During application, only small quantities should be decanted from the original container into the application container.

**Residues of unused should not be returned from the application container to the original container.**

**Applicators dampened with water should not be used. If dirt appears on the applicators during coating, they should be replaced with clean applicators to avoid dirt entering into the coating.**

The applicators cannot be reused once the coating has been applied.

Solutions that are no longer useable must be disposed of properly (Follow Local regulations).

If the solution in the application container solidifies or deposit forms, it can no longer be used.

---



DANIEL@DCIFILMS.COM  
305-640-0295

WWW.DCIFILMS.COM

7866 NW 62ND STREET  
MIAMI, FL 33166, USA

# NANO STONE

---



## CURING

### STEP 5

- NANO STONE is dry-to-touch after **2 Hours**.
  - Is fully effective after **24 hours** ambient temperature.
  - The effect will last at least **48- 60 months**.
- 

COMPLETE TECHNICAL DATA & SAFETY MEASURES ON TDS, ASK YOUR DISTRIBUTOR IF NECESSARY.



---

DANIEL@DCIFILMS.COM  
305-640-0295  
WWW.DCIFILMS.COM

7866 NW 62ND STREET  
MIAMI, FL 33166, USA