

NT CERAMIC



APPLICATION INSTRUCTIONS



USE MASK



USE GLOVES



KEEP AWAY FROM
OPEN FIRE



MAKE SURE FOR
GOOD VENTILATION

INSTRUCTIONS AND USE SHOULD BE FOLLOWED
STRICTLY.



CONDITION OF SUBSTRATE

- The substrate to be coated must be completely clean, grease free and **absolutely dry**.
 - In contact with a damp substrate surface it reacts prematurely and cannot form a permanent seal.
 - The substrate temperature must be between 41° F / 86° F, the relative humidity at 30-60 %.
 - Keep away from open fire and make sure for a good ventilation.
 - Do not apply **under sunlight**.
 - Do not apply in damp or very **humid** conditions.
 - Do not apply the coating in **hot surfaces**.
 - Do not apply in ceramic surfaces which has been coated previously (Remove old residues).
-



DANIEL@DCIFILMS.COM
305-640-0295
WWW.DCIFILMS.COM

7866 NW 62ND STREET
MIAMI, FL 33166, USA

NT CERAMIC



PREPARATION

STEP 1

- We recommend that the surface is deeply clean, washed with water and neutral cleaner.
- Thoroughly rinse the surface with clear water (without cleaner) to remove cleaner residues.
- Dry the glass surface with an absorbent clean cloth.
- Repeat Step 1 step until the cloth is no dirt or grime.
- Make sure the surface is dry, free of grease, dust, etc. (use alcohol basic and neutral cleaners non acids).
- Use alcohol deeply to clean any residues of previous cleaners (Follow MSDS instructions for alcohol use).

Do not consider that the surface is clean only by wiping and drying.



APPLICATION

STEP 2

- Use pre-impregnated **lint free cloth 0.34 oz** Which is approximately optimal amount for a 10 x 10 inches (**as a reference quantity**).
- Ensure full coverage and **work quickly** with both vertical and horizontal actions.



DANIEL@DCIFILMS.COM
305-640-0295

WWW.DCIFILMS.COM

7866 NW 62ND STREET
MIAMI, FL 33166, USA

NT CERAMIC



FINISHING

STEP 3

- Leave the solution remains in the surface for **50 minutes**.
- Removed silane residues, buff the surface with a clean and dry soft microfiber cloth or clean and dry kitchen roll preferably.
- For big surfaces can be used a buffer machine with very soft cloth for finishing.



CURING

STEP 4

- The product take **10 hours** to fully cure.
- The surface can be exposed to water or rain **2 hour** after application.
- The effect of the products will last at least **6 months**

COMPLETE TECHNICAL DATA & SAFETY MEASURES ON TDS, ASK YOUR DISTRIBUTOR IF NECESSARY.



DANIEL@DCIFILMS.COM
305-640-0295
WWW.DCIFILMS.COM

7866 NW 62ND STREET
MIAMI, FL 33166, USA