

NT SOLAR



APPLICATION INSTRUCTIONS



USE MASK



USE GLOVES



KEEP AWAY FROM
OPEN FIRE



MAKE SURE FOR
GOOD VENTILATION

INSTRUCTIONS AND USE SHOULD BE FOLLOWED
STRICTLY.



CONDITION OF SUBSTRATE

- The substrate to be coated must be completely clean, grease free and **absolutely dry**.
- In contact with a damp substrate surface it reacts prematurely and cannot form a permanent seal.
- The substrate temperature must be between 41° F / 86° F, the relative humidity at 30-60 %.
- Keep away from open fire and make sure for a good ventilation.
- Do not apply under **sunlight**.
- Do not apply in damp or **very humid conditions**.
- Do not apply the coating in **hot surfaces**.

Do not apply in glass surfaces which has been coated previously (Remove old residues).

FOR SOLAR PANELS APPLICATION IT IS RECOMMENDED THEIR APPLICATION DURING CLOUDY PERIODS AND OR BEFORE SUNSET (SPRAY APPLICATION RECOMMENDED).



DANIEL@DCIFILMS.COM
305-640-0295
WWW.DCIFILMS.COM

7866 NW 62ND STREET
MIAMI, FL 33166, USA

NT SOLAR



PREPARATION

STEP 1

- We recommend that the glass surface is deeply clean, **washed with water and neutral cleaner.**
 - Thoroughly rinse the glass surface with clear water (without cleaner) to remove cleaner residues.
 - Dry the glass surface with an absorbent clean cloth or with air pressure drying process.
-



APPLICATION

STEP 2

- Use pre-impregnated lint free cloth. Use 4 oz which is approximately optimal amount for a 64 x 39 inches surface.
 - After glass preparation. Use recommended quantity to prevent non transparent surfaces.
 - Ensure full coverage and work quickly with both vertical and horizontal actions.
-



FINISHING

STEP 3

- Leave the solution remains in the surface for 30 minutes.
 - The surface may look "cloudy" after drying time.
-



NT SOLAR

- Removed silane residues, buff the surface with a clean and dry soft microfiber cloth or clean and dry kitchen roll preferably.
 - For big surfaces can be used a buffer machine with very soft cloth for finishing.
-



CURING

STEP 7

- **The product take 10 hours to fully cure.**
 - **The surface can be exposed to water or rain 1 hour after application.**
 - **The effect of the products will last at least 6 to 9 months average.**
-

COMPLETE TECHNICAL DATA & SAFETY MEASURES ON TDS, ASK YOUR DISTRIBUTOR IF NECESSARY.



DANIEL@DCIFILMS.COM
305-640-0295
WWW.DCIFILMS.COM

7866 NW 62ND STREET
MIAMI, FL 33166, USA